

back to business RE-OPENING CHECKLIST

Ergoline



1. DISINFECT

Did you leave units on?

– Using the internal breaker, power down each unit, and fully disinfect. Once unit has been disinfected and all components are dry, power back on, one unit at a time, allowing 15 second intervals between.

Did you turn units off?

– Disinfect all equipment. Once unit has been disinfected and all components are dry, power back on, one unit at a time, allowing 15 second intervals between.

Note: It is very important to follow these steps as instructed, turning too many units on at once can cause a power fluctuation (black out/brown out/voltage spike) which could result in damage to the tanning bed.



2. PREVENTATIVE MAINTENANCE

We recommend performing a preventative maintenance check on all equipment prior to reopening.

The preventative maintenance steps for each equipment model can be found in the Ergoline user manual.

If you do not have a Ergoline user manual, please visit <http://support.jkamerica.com> or contact JK Service at 877.445.0624 for further assistance.

Note: This information can be found in the Cleaning and Maintenance section of the Ergoline user manual.

back to business RE-OPENING CHECKLIST

Ergoline

3. TEST CYCLE - TANNING SESSIONS

After equipment has been disinfected and powered back on, it is important to run test sessions to ensure all components are working properly. (Beds, Lamps T-max timers and SUNLYNC software).

The equipment and lamps can have the tendency of "slow" starting after sitting for an extended period with no usage. It is recommended to run a minimum of 2-3 full sessions to allow the equipment and lamps to fully acclimate.

1. Run 3 cycles of test sessions and test times for each piece of equipment using the t-max timer with the SUNLYNC software.
2. If you have in house technicians and/or an asset management ticketing system, please follow standard process and procedures for reporting issues. If additional assistance is required, please contact JK Service 877.244.6183 JK Lamps 800.793.6760 or Sunlync 866.786.5962



4. Disinfect all equipment a 2nd time once all beds are operating properly.
5. Remove all eyewear and replace with disposable or individual.
6. Clean tanning rooms thoroughly, sanitize floors, clean door handles, and any surface that is routinely touched during a session.

These are our standard cleaning guidelines to get equipment ready for reopening. This does not address the required disinfecting that will be in place once open. Further guidance on disinfecting to follow in later communication.